

# DIPPING PREP SHEET



1182 Bethel Drive

Eugene, Oregon 97402

1-877-412-8806

info@metaldipping.com

**Remove All Parts:** Unbolt / Remove all removable parts: doors, door hinges, fenders, fender extensions, Aarms, window & door regulators, Everything!

**Remove All:** Removable items, fuel & brake lines, trim, weather strip, wiring, pedals, clips, insulation

**Remove All:** Hinges including trunk hinge springs (if removable)

**Remove All:** Bolts should be left out so we can clean each and every hole

**Remove All:** Aluminum tags and parts should be removed

**Remove All:** Pot Metal emblems and parts should be removed

**Remove All:** Floor plugs, drain holes/plugs should be left open for drainage

**Remove All:** General debris, garbage, dirt, rodent droppings should all be removed prior to brining your vehicle to us

**Remove All:** Wood and glass

**Remove All:** Undercoating, remove all you can prior to dipping

**Remove All:** Rubber bump stops and rubber straps

**Remove All:** Trim, stainless & aluminum trim should be removed

**Remove All:** Backing plates (if removable)

**Clear Coat Prep:** Shiny clear coat or heavy clear coat must be well scuffed and cut through.  
Removal of heavy or shiny clear coat is required so the chemical cleaning can work best.

**Bracing:** Angle steel is best for bracing upper door openings on convertible car bodies

**Body Carts:** Please do not attached car bodies or pickup cabs to a cart, jig, or any moving apparatus.  
We want and need just the car body or pickup cab.  
If attaching it is required for your transportation please plan to remove it or separate it upon arrival.

**BUSINESS HOURS:** 8:30 to 4:30 Monday - Thursday

8:30 to 4:00 Friday