

# DIPPING PREP SHEET

1182 Bethel Drive

Eugene, Oregon 97402

1-877-412-8806

info@metaldipping.com

BUSINESS HOURS:

8:30 to 4:00 Monday - Friday



## Customer Prep Before Dipping

### **Remove All**

- Nuts
- Bolts
- Screws
- Clips
- Springs
- Emblems
- Wiring
- Clamps / Hoses / Lines
- Tape
- Wood
- Insulation
- Aluminum
- Dynamat or other aftermarket sound deadener
- Rubber and Plastic Grommets & Plugs
- Loose Debris (shop vac or pressure wash to remove all loose debris, garbage, dirt, screws, and all other loose material of any kind)
- Do Not Leave Bolts Anywhere
- Do Not Leave Removable Trunk Springs In Your Vehicle
- Do Not Use Tube Steel For Bracing, Use Angle
- Do Not bring your car on a rotisserie

We want to clean each and every part the very best we can.

Proper preparation is the very important first step

If it's welded it stays together.

If it's not welded together it need to be removed / separated.