

DIPPING PREP SHEET

1182 Bethel Drive

Eugene, Oregon 97402

1-877-412-8806

info@metaldipping.com

BUSINESS HOURS:

9:00 to 4:00 Monday - Friday

Sat/Sun by appointment



Customer Prep Before Dipping

Please Remove All

- Nuts - Bolts - Screws - Clips
- Springs - Emblems - Wiring - Clamps/Hoses/Lines
- Tape - Wood - Insulation
- Headliner matting - Trunk Lid Matting (all that you can remove)
- Headliner trim, interior trim panels
- All Aluminum (including aluminum cowl tags & VIN tags or plates)
- Dynamat or other aftermarket sound deadener
- Floor Plugs - Drain Plugs - Rubber & Plastic Plugs
- Removal trunk springs
- Loose Debris - Garbage - Dirt - Screws -
- All other loose material of any kind
- Shop vac and/or pressure wash to remove as needed
-
-
-
-
-
-
- Please Do Not Leave Bolts Anywhere
- Please Do Not Leave Removable Trunk Springs In Your Vehicle
- Please Do Not Use Tube Steel For Bracing, Use Angle
- Please Do Not bring your car on a rotisserie

We want to clean each and every part the very best we can.

Proper preparation is the very important first step

If it's welded it stays together.

If it's not welded together it need to be removed / separated.