

DIPPING PREP SHEET

1182 Bethel Drive

Eugene, Oregon 97402

1-877-412-8806

info@metaldipping.com

BUSINESS HOURS:
9:00 to 4:00 Monday - Friday
Sat/Sun by appointment



Customer Prep Before Dipping

Remove All

- Nuts - Bolts - Screws - Clips
- Springs - Emblems - Wiring - Clamps/Hoses/Lines
- Tape - Wood - Insulation - Zip Ties
- Headliner matting - Trunk Lid Matting (all that you can remove)
- Headliner trim, interior trim panels
- All Aluminum (including aluminum cowl tags & VIN tags or plates)
- Dynamat or other aftermarket sound deadener
- Floor Plugs - Drain Plugs - Rubber & Plastic Plugs
- Removal trunk springs
- Loose Debris - Garbage - Dirt - Screws -
- All other loose material of any kind
- Shop vac and/or pressure wash to remove as needed

- Please do not transport your vehicle on the chassis without fully separating the body & chassis first
- Please Do Not leave bolts anywhere
- Please Do Not leave removable door hinges attached
- Please Do Not use tube steel for bracing, use angle
- Please Do Not bring your car on a rotisserie

We want to clean each and every part the very best we can.

Proper prep is the very important first step

If it's welded or permanently riveted it stays together.

If it's not welded together it need to be removed / separated.